## DIGIEVER Network Camera Compatibility List

The list is applied for DIGIEVER NVR firmware 78-2 version or later

O DIG	GIEVER N	VR supports the camera feature	* Camera does not support the feature	e	Blank means the feature is NOT supported or verified by DIGIEVER
<b>(P)360</b>	)° Panoran	nic	© NVR support camera hardware dewa	arp setting	S NVR support camera software dewarp
🔶 Car	mera take	es more than 1CH, needed to be a	dded via video sever method		
	1	1. Audio Detection	5. Intrusion Detection	9. People Counting 1	g Threshold Alarm
IVA	Event 2	2. Advanced Motion Detection	6. Loitering Detection	10. Temperature De	Detection
N	No.: 3	3. Human Detection	7. Foreign Object Detection	11. Camera Tamperi	ering Detection
	4	4. Cross Line Detection	8. Missing Object Detection	12. Object Status Ch	Change

## Supported in the NVR latest version Copyright <sup>®</sup> DIGIEVER Corporation All Rights Reserved

## Copyright \* DIGIEVER Corporation All Rights Reserved \* Please contact DIGIEVRE sales for updated information

nd	Camera Model	Con	npres	sion Fo	rmat	Z	oom Co	ntrol	B	asic Funct	ion			Adva	nced Functio	on	Remark	
		MJPEG	MP -4	1 H 26	64 H.2	65 Pan/ Tilt		Digital Zoom		Digital Input	Audio (Besides HTTP)	Two- way Audio	Edge Record (RTSP)	Supported IVA	Al Search (Metadata)	Advanced Right-Click Menu	Camera Firmware/ Note	Not support in other platform CMS, VD, SS
	VIVOTEK cameras			- 1							· ····,	Addio	(1151)	1				Civio, VD, 55
	VIVOTEK AB5353H	•			*	*	*		•	•	•	*				1		
	VIVOTEK AD5196	•	*		_	*	*	<b>•</b>	Ĭ	*	*	*					0100f	
	VIVOTEK AF5127	•	•		_	•	•	•	•	•	•	*						
	VIVOTEK AF5127V DS	•	Ō		*	-	•	•	•	•	•	*						
	VIVOTEK AF5147V PCS	•	Ì		*	*	*	•	•	•	- Č	*					0100c	
	VIVOTEK AS5336E	•			*	•	•	•	•	•	•	*						
	VIVOTEK BB5116	•			*	•	•	•	•	•	•	*						
	VIVOTEK BB5315	•			*	*	*	•	•	•	•	*						
	VIVOTEK BD5115	•			*	*	*	•	•	•	•	*						
	VIVOTEK BD5336	•			*	•	•	•	•	•	•	*						
	VIVOTEK BS5332E		•		*	•	•		•	•	•	*						
	VIVOTEK CC8130	•	*	•	*	*	*	•	•	•	•	*					0201a	1
	VIVOTEK CC8130(HS)	•	*	Ĭ	*	*	*	<b>•</b>	•	•	•	*					0201a	1
	VIVOTEK CC8160	•	*	•	*	*	*	•	•	*	•	*					0113a	
	VIVOTEK CC8370-HV DS	•	*	•	*	*	*	•	•	*	•	*					0113a	
	VIVOTEK CC8371-HV	•	*	•	*	*	*	•	•	•	•	•					0113a	
	VIVOTEK CC9381-HV	•	*	•		) *	*	•	•	*	•	*					0113a	
	VIVOTEK CD8371-HNTV	•	*	•	*	*	*	•	•	•	•	•					0113a	
	VIVOTEK CD8371-HNVF2	•	*	•	*	*	*	•	•	•	•	•					0113a	
	VIVOTEK CD9381-HNTV	•	*	•	*	*	*	•	•	•	•	•			•		1.2201.37.01g	
	VIVOTEK CD9381-HNVF2	•	*	•	*	*	*	•	•	•	•	•			•		1.2201.37.01g	
	VIVOTEK FD7131	•		, *	*	*	•	•	•	•	•	•						
	VIVOTEK FD7141	•		, *	*	*	*	•	•	•	•	•					0100g	
	VIVOTEK FD8131	•			*	*	*	•	•	•	*	*						
	VIVOTEK FD8131V	•			*	*	•	•	•	*	*	*						
	VIVOTEK FD8133	•			*	*	*	•	•	•	*	*						
	VIVOTEK FD8133V	•			*	*	*	•	•	•	*	*						
	VIVOTEK FD8134	•	•		*	*	*		•	•	*	*						
	VIVOTEK FD8134-SS	•	•		*	*	*		•	*	*	*						
	VIVOTEK FD8134V				*	*	*		•	•	*	*						
	VIVOTEK FD8135H	•			*	•	•		•	•	•	•						
	VIVOTEK FD8136	•	•		*	*	*	•	•	•	•	*						
	VIVOTEK FD8137H	•	*	•	*		•	•	•	•	•	*						
	VIVOTEK FD8137HV		*	•	*	*			•			*						
	VIVOTEK FD8138H	•	*	•	*	*	*		•	•	•	*					0100e	
	VIVOTEK FD8151V		*	•	*	*	*		•	•		*						
	VIVOTEK FD8152V	•	*		*	*	*					*						
	VIVOTEK FD8154		*		*	*	*					*					0201a	
	VIVOTEK FD8154V		*		*	*	*					*					0201a	
	VIVOTEK FD8161				*													
	VIVOTEK FD8162				*	*	*											
	VIVOTEK FD8163				*													
	VIVOTEK FD8164		*		*	*	*		•			*					0100d	
	VIVOTEK FD8164V		*	•	*	*	*		•			*						
	VIVOTEK FD8166	•	*	•	*	•	•		•			*						
	VIVOTEK FD8166A	•	*	•	*	*	*		•	•		*					0113a	
	VIVOTEK FD8166A-N		*	•	*	*	*	•	•	*	•	*					0113a	

Update: Oct. 2024

		npressio	111011	ilat	200	om Con	101	Dd	sic Functi	on			Adva	nced Functio	n	Remark	
	MJPEG	MPEG -4	H.264	H.265	Pan/ Tilt	Optical Zoom	Digital Zoom	Motion Detection	Digital Input	Audio (Besides HTTP)	Two- way	Edge Record	Supported IVA	Al Search (Metadata)	Advanced Right-Click Menu	Camera Firmware/ Note	Not suppo other plat
VOTEK FD8167	•	*	•	*	*	*	•	•	•	нпр) •	Audio	(RTSP)					CMS, VE
VOTEK FD8167A	•	*	•	*	*	*	•		*	*	*					0113a	
VOTEK FD8167A-S	•	*	•	*	*	*	•		*	*	*					0113a	
/IVOTEK FD8167-T	•	*		*	*	*	•	•	•	•	•					0100f	
/IVOTEK FD8169	•	*	•	*	*	*	•	•	*	*	*					0100f	
VIVOTEK FD8169	•	*	•	*	*	*	•	•	*	*	*					0113a	-
VIVOTEK FD8169A-S		*	•	*	*	*	•	•	*	*	*					0113a	+
VIVOTEK FD816BA-HF2		*	•	*	*	*				•	•					0113a	+
VIVOTEK FD816BA-HF2		*		*	*	*			•	-	-					0113a	+
	•	*	•	*	*	*	•	-	•	•	•						
VIVOTEK FD816B-HF2	•	*		*	*	*		•	•	•	•					0113a	
VIVOTEK FD816B-HT	•	*	•	*	*	*		•	*	•	•					0113a	
VIVOTEK FD816C-HF2	•	-	•	*	*		•	•		•						0113a	
VIVOTEK FD8171	•	•	•	*	*	*	•	•	*	•	•						
VIVOTEK FD8177-H	•	_	•				•	•		•						0113a	
VIVOTEK FD8177-HT	•	*		*	*	*	•	•		•	•					0113a	
VIVOTEK FD8179-H	•	*		*	*	*	•	•	*	•	*					0113a	
VIVOTEK FD8181	•	*		*	*	*	•	•								0101c	
VIVOTEK FD8182-F1	•	*	•	*	*	*		•	•							0113a	
VIVOTEK FD8182-F2		*		*	*	*	•	•	•	•						0113a	
VIVOTEK FD8182-T		*	•	*	*	*	•	•		•						0113a	_
VIVOTEK FD8335H	•	•		*	*	*	•	•	•	•							
VIVOTEK FD8338HV		*		*	*	*	•	•	•	•	*					0100d	
VIVOTEK FD8355EHV		*		*	*	•	•	•	•	•							
VIVOTEK FD8361		•		*	*	*	•	•	•	•							
VIVOTEK FD8361L				*	*	*		*	*								
VIVOTEK FD8362				*	*	*	•	•		•							
VIVOTEK FD8362E	•	•		*	*	*	•	•	•	•							
VIVOTEK FD8363	•	•	•	*	*	*	•	•	•	•							
VIVOTEK FD8365EHV	•	*	•	*	*	*	•	•	•	•	•						
VIVOTEK FD8365HV		*	•	*	*	*	•	•	•	•							
VIVOTEK FD8366-V	•	*	•	*	*	*	•	•	•	•	*					0113a	
VIVOTEK FD8367A		*	•	*	*	*		•	*	*	*					0200a_7	
VIVOTEK FD8367A-V	•	*	•	*	*	*	•	•		•	*					0113a	
VIVOTEK FD8367-TV	•	*	•	*	*	*	•	•	•	•						0100d	-
VIVOTEK FD8367V	ė	*	Ŏ	*	*	*	ě	- Č	*	*	*					0200a_7	
VIVOTEK FD8369A-V	•	*	<b>•</b>	*	*	*	•	- Č	•	•	*					0113a	-
VIVOTEK FD836BA-EHTV	•	*	•	*	*	*	•	•	•	•	•					0113a	1
VIVOTEK FD836BA-EHVF2	•	*	<b>•</b>	*	*	*	•	- i	•	•	•					0113a	-
VIVOTEK FD836BA-HTV	•	*	Ĭ	*	*	*	•	•	•		ě					0113a	-
VIVOTEK FD836BA-HVF2	•	*	•	*	*	*	•		•		•					0113a	+
VIVOTEK FD836B-EHTV	•	*	•	*	*	*	•		•	•	•					0113a	+
VIVOTEK FD836B-EHVF2	•	*	•	*	*	*	•				•					0113a	+
VIVOTEK FD836B-HTV		*	•	*	*	*										0113a	+
VIVOTEK FD836B-HVF2		-		*	*		-				-						+
	•		•	*	*	•	•			•	•					0113a	+
VIVOTEK FD8371EV				*	*	•		•	•	-	-						+
VIVOTEK FD8371V VIVOTEK FD8372	•	*		*	*	*	•	•		•	•						+
	•	*	•	*	*	*	•	•		•	*						+
VIVOTEK FD8373	•	*	•	*	*	*	•	•	*	•							+
VIVOTEK FD8373-EHV	•		•				•	•		•	•						+
	•	*	•	*	*	*	•	•	•	•	•					0113a	+
	•	*	•	*	*	*	•	•	•	•	•					0113a	
VIVOTEK FD8377-HV	•	*	•	*	•	•	•	•	*	*	*					0113a	+
VIVOTEK FD8379-HV	•	*	•	*	*	*	•	•	•	•	*					0113a	+
VIVOTEK FD8381-EV	•	*	•	*	*	*	•	•	•	•	•					0100x_2_20	
VIVOTEK FD8382-ETV	•	*	•	*	*	*	•	•	•	•	•					0113a	
VIVOTEK FD8382-EVF2	•	*		*	*	*	•	•	•	•	•					0113a	
VIVOTEK FD8382-TV	•	*		*	*	*	•	•	•	•	•					0113a	
	•	*	•	*	*	*	•	•	•	•	•					0113a	
VIVOTEK FD8382-VF2													_				
VIVOTEK FD8382-VF2 VIVOTEK FD9165-HT	•	*			*	*	•	•		•						0113d	

Camera Model	Col	mpres	sion	Format	Z	oom Cor	itrol	Ва	isic Functi	on			Adva	nced Functio	n	Remark	
	МЈРЕС	3 MP		1.264 H.265	Pan/ Tilt	Optical Zoom	Digital Zoom	Motion Detection	Digital Input	Audio (Besides	Two- way	Edge Record	Supported IVA	Al Search (Metadata)	Advanced Right-Click Menu	Camera Firmware/ Note	No oth
VIVOTEK FD9167-H		*			*	*			-	HTTP)	Audio	(RTSP)				0113a	C
		*	-	• •	*	*		•	•	•	•						
VIVOTEK FD9167-HT	•	_		• •	_	*	•	•	•	•	•					0113a	
VIVOTEK FD9171-HT	•	*		-	*		•	•	•	•	•					0113a	
VIVOTEK FD9181-HT	•	*		• •	*	*	•	•	•	•	•					0113a	
VIVOTEK FD9187-H		*		• •	*	*		•	•	•						0113d	
VIVOTEK FD9187-HT	•	*	*	• •	*	*	•	•	•	•	•		9			0113d	
VIVOTEK FD9187-HT-A		*	*	• •	*	*		•								0104a_onvif1	
VIVOTEK FD9187-HT-V3		*	*	• •	*	*		•		•	•			•		1.2201.37.01g	
VIVOTEK FD9189-H		*	*	• •	*	*	•	•	*		*					0113d	
VIVOTEK FD9189-H-v2		*	*	• •	*	*	•	•	*	•	*					1.2102.33.01k	
VIVOTEK FD9189-HM	•	*		•••	*	*	•	•	*	- Č	*					0113d	
VIVOTEK FD9189-HT	•	*		• •	*	*	•	•	*		*					0113d	
		*			*	*		-	*	*	*						
VIVOTEK FD9360-H	•	_		• •	_		•	•	-							0113a	
VIVOTEK FD9365-EHTV	•	*		• •	*	*	•	•	•	•	•					0113d	
VIVOTEK FD9365-EHTV-A		*		• •	*	*	•	•	•	•	•						
VIVOTEK FD9365-EHTV-V2		*	*	• •	*	*		•	•	•		•		•		1.2201.37.01g	
VIVOTEK FD9365-HTV		*	*	• •	*	*		•	•	•	•					0113d	
VIVOTEK FD9365-HTV-A	•	*	*	• •	*	*		•			•						
VIVOTEK FD9365-HTVL	•	*	•	• •	*	*	•	•	•	•	•					0113d	
VIVOTEK FD9366-HV	•	*	*	• •	*	*	•	•	•	•	*					0222g	
VIVOTEK FD9367-EHTV	•	*	,	•••	*	*	•		•	•	•					0113d	
VIVOTEK FD9367-HTV		*		• •	*	*	•				•					0113a	
		*			*	*	-		-	-	-						
VIVOTEK FD9367-HV	•	_		• •	_	-	•	•	•	•	•	-				0113a	
VIVOTEK FD9368-HTV	•	*		• •	*	*	•	•		•	*	•				0223b	
VIVOTEK FD9368-HTV	•	*		• •	*	*		•	*	•	*					2.2002.13.01h	
VIVOTEK FD9369	•	*	*	• •	*	*	•	•	*	•	*					1.2101.41.01	
VIVOTEK FD9371-EHTV	•	*	*	• *	*	*		•								0113a	
VIVOTEK FD9371-HTV		*	*	• *	*	*		•	•	•	•					0113a	
VIVOTEK FD9380-H	•	*	•	••	*	*	•		*	•	*					0113a	
VIVOTEK FD9381-EHTV		*	, †	• •	*	*	•	- i	•	- i	•					0113a	
VIVOTEK FD9381-EHV				• *	*	*			•		*						
		*			*	*	-		•	•						0113a	
		*			*	*	•		*	-	*			-		0113a	
VIVOTEK FD9383-HTV	•	_		• •			•	•		•				•			
VIVOTEK FD9383-HV		*		• •	*	*	•	•	*	*	*			•		1.2303.43.01h	
VIVOTEK FD9387-EHTV		*	*	• •	*	*		•	•		•					0113d	
VIVOTEK FD9387-EHTV-A		*	*	• •	*	*		•								0100m	
VIVOTEK FD9387-EHTV-V3		*	*	• •	*	*		•	•	•				•		1.2201.37.01g	
VIVOTEK FD9387-EHV		*	*	• •	*	*	•	•	•	•	•					0113d	
VIVOTEK FD9387-HT	•	*	•	• •	*	*	•	•	•	•	*					0111c	
VIVOTEK FD9387-HTV	•	*		•••	*	*	•	- i	•		*					0113d	
VIVOTEK FD9387-HTV-A		*		•••	*	*					•					0100m	
	•	*			*	*					-						
VIVOTEK FD9387-HV	•	_		• •			•	•	•	•	•					0113d	
VIVOTEK FD9388-HT	•	*		• •	*	*	•	•	*	•	*					0113a	
VIVOTEK FD9388-HTV		*		• •	*	*	•	•	*	•	*					0113a	
VIVOTEK FD9389-EHMV		*	<u>،</u>	• •	*	*	•	•	*	•	*					0113d	
VIVOTEK FD9389-EHTV		*	*	• •	*	*		•	*	•	*					0113d	
VIVOTEK FD9389-EHTV-v2		*	• T	• •	*	*		•	*	•	*					1.2204.33.01d	
VIVOTEK FD9389-EHV	l l l l l l l l l l l l l l l l l l l	*	•	• •	*	*	•	Ŏ	*	<b>I</b>	*					0113d	
VIVOTEK FD9389-HM	•	*	, †	•••	*	*		- č	*		*					0113d	
VIVOTEK FD9389-HMV		*		•••	*	*	•	•	*		*					0113d	
		*			*	*		-	*		*					0113d	
VIVOTEK FD9389-HTV	•			• •	_		•	•	*	•							
VIVOTEK FD9389-HV	•	*		• •	*	*	•	•		•	*					0113d	
VIVOTEK FD9391-EHTV	•	*		• •	*	*	•	•	•	•	•					0113d	
VIVOTEK FD9391-EHTV-v2	•			• •	-	*	•	•	•	•				•		1.2201.37.01g	
VIVOTEK FE8171V				• *	*	*	•	•	•	•	•					0100g	
VIVOTEK FE8172				• *	*	*		•									
VIVOTEK FE8172V DC	)6 🔴			• *	*	*	•	•	•	•	•						
VIVOTEK FE8173				• *	*	*	•	•	•	•	•						
VIVOTEK FE8174		*		• *	*	*	•	•	•		•					0100f	
VIVOTEK FE8174V DO				• *	*	*	•		•	•	•						
PUC	•			• *							*						<b>—</b>

Camera Model	Com	pression	on Format	Z	oom Cor	ntrol	Ba	asic Functi	ion			Adva	nced Functio	n	Remark	
	MJPEG	MPEG -4	H.264 H.265	Pan/ Tilt	Optical Zoom	Digital Zoom	Motion Detection	Digital Input	Audio (Besides HTTP)	Two- way Audio	Edge Record (RTSP)	Supported IVA	Al Search (Metadata)	Advanced Right-Click Menu	Camera Firmware/ Note	Not support in other platform CMS, VD, SS
VIVOTEK FE8181 DCS	•	*	• *	*	*	•	•		•	•	(11317				0100f	
VIVOTEK FE8181V DCS	•	*	• *	*	*	•	•	•	•	•					0100f	ĺ
VIVOTEK FE8182 DS	•	*	• *	*	*	•	•	•	•	*					0113a	[
VIVOTEK FE8191	•	*	• *	*	*	•	•	•	•	•					0101c	Í
	-	*	-	*	*	-	-		-	*						l
VIVOTEK FE9180-H @§	•		• •			•	•	•	•						0113a	l
VIVOTEK FE9180-H-V2 PS	•	*	• •	*	*	•	•	•	•	•	•				2.2201.13.01c	ł
VIVOTEK FE9181-H (P)S	•	*	• •	*	*	•	•	•	•	•					0113a	1
VIVOTEK FE9182-H @®	•	*		*	*	•	•	*	•	*					0113a	l
VIVOTEK FE9380-HV	•	*	• •	*	*	•	•		•						0222k	l
VIVOTEK FE9381-EHV (D)(S) VIVOTEK FE9382-EHV	•	*		*	*	•	•	•	•	•					0113a 0113a	l
		*		*	*				-	-	•				2.2103.34.01h	l
VIVOTEK FE9382-EHV-v2 DS	•	ļ	• •			•	•	•	•	•	•		•		1.2301.37.01e	l
VIVOTEK FE9391-EHV-v2 DCS	•	*	• •	*	*		•			•	•		•		Support HW Dewarp(Stream1)	1
VIVOTEK FE9391-EV DS	•	*	• •	*	*		•	•	•	•					0113d	l
VIVOTEK FE9582-EHNV @S	•	*	• •	*	*	•	•	•	•						0113a	ĺ
VIVOTEK IB8156-C	<b>•</b>	*	• *	*	*	Ŏ	•	•	•	*						í
VIVOTEK IB8168-C	ė	*	• *	*	*	•	•	•	•	*						i
VIVOTEK IB8338	•	*	• *	*	*	•	•	•	*	*					0102a	í
VIVOTEK IB8338-H	•	*	• *	*	*	Ó	•	•	•						0100g	
VIVOTEK IB8338-HR	•	*	• *	*	*		•	•	•							Í
VIVOTEK IB8354-C	•	*	• *	*	*	•	•	•	•	*					0100g	Í
VIVOTEK IB8360		*	• *	*	*		•	*	*	*					0113a	l
VIVOTEK IB8360-W		*	• *	*	*		•	*	*	*					0113a	1
VIVOTEK IB8367		*	• *	*	*		•		•	•						1
VIVOTEK IB8367A		*	• *	*	*		•	*	*	*					0113a	
VIVOTEK IB8367-R	•	*	• *	*	*	•	•	*	•	•					0100e	1
VIVOTEK IB8367-T	•	*	• *	*	*	•	•	•	•						0101c	4
VIVOTEK IB8369	•	*	• *	*	*	•	•	•	•	*					0101c	
VIVOTEK IB8369A	•	*	• *	*	*		•	*	*	*					0113a	1
VIVOTEK IB836BA-EHF3	•	*	• *	*	*	•	•	•	•						0113a	l
VIVOTEK IB836BA-EHT	•	*	• *	*	*	•	•	•	•	•					0113a	1
VIVOTEK IB836BA-HF3	•	*	• *	*	*	•	•	•	•	•					0113a	l
VIVOTEK IB836BA-HT	•	*	• *	*	*	•	•	•	•	•					0113a	ł
VIVOTEK IB836B-EHF3	•	*		*	*	•	•	•	•	•					0113a	l
	•	*		*	*		•	•	•	•					0113a	
	•	*		*	*		•	•	•	•					0113a 0113a	l
VIVOTEK IB836B-HT VIVOTEK IB8373	•	*		*	*	•	•	•	*	*					01134	l
VIVOTEK IB8373-EH		*	• *	*	*	•			•	•					01000	[
VIVOTEK IB8377-EHT		*	• *	*	*		•	•	•	•					0113a	
VIVOTEK IB8377-H	•	*	• *	*	*	-	•	•		*					0113a	1
VIVOTEK IB8377-HT		*	• *	*	*	-	•	•	•	•					0113a	(
VIVOTEK IB8379-H	•	*	• *	*	*	•	•	•	•	*					0113a	
VIVOTEK IB8381	<b>•</b>	*	• *	*	*	•	•	•	•						0100x_2_20	Í
VIVOTEK IB8381-E	•	*	• *	*	*	•	•	•	•	•					0100x_2_20	
VIVOTEK IB8382-EF3	•	*	• *	*	*	•	•	•	•	•					0113a	1
VIVOTEK IB8382-ET	•	*	• *	*	*	•	•	•	•						0113a	
VIVOTEK IB8382-F3	•	*	• *	*	*										0113a	
VIVOTEK IB8382-T	•	*	• *	*	*		•		•						0113a	
VIVOTEK IB9360-H	•	*	• •	*	*	•	•	*	•	*					0113a	
VIVOTEK IB9365-EHT	•	*	• •	*	*		•	•	•	•					0113d	
VIVOTEK IB9365-ЕНТ-А	•	*	• •	*	*	•	•	•	•							
VIVOTEK IB9365-EHTV-V2	•	*	• •	*	*	•	•	•	•	•	•		•		1.2201.37.01f	l
VIVOTEK IB9365-НТ	•	*	• •	*	*	•	•	•	•	•					0113d	I
VIVOTEK IB9365-HT-A	•	*	• •	*	*	•	•	•	•	•						l
VIVOTEK IB9367-EH	•	*	• •	*	*	•	•	•	•	•					0113a	l
VIVOTEK IB9367-EHT	•	*	• •	*	*	•	•	•	•	•	-				0113a	l
VIVOTEK IB9367-EHT-v2	•	*	• •	*	•	•	•	•	•	•	•				1.2103.33.02a	l
VIVOTEK IB9367-H	•	*		*	*		•	•	•	•					0113a	
VIVOTEK IB9367-HT		*	• •	*	*		•								0113a	1

Camera Model	Com	pressi	on For	mat	Zo	oom Cor	ntrol	Ba	isic Functi	ion			Adva	nced Functio	n	Remark	
	MJPEG	MPEG -4	й н.264	H.265	Pan/ Tilt	Optical Zoom	Digital Zoom		Digital Input	Audio (Besides HTTP)	Two- way	Edge Record (RTSP)	Supported IVA	Al Search (Metadata)	Advanced Right-Click Menu	Camera Firmware/ Note	Not su other p
VIVOTEK IB9368-HT	•	*	•	•	*	•	•	•	*	*	Audio *					0223b	CMS
VIVOTEK IB9369	•	*			*	*			*	*	*					1.2101.41.01	
VIVOTEK IB9305	•	*		*	*	*		•	•	•	•					0113a	
VIVOTEK IB9371-HT			*	•	*	*	•			-						0113a	
		*			*	*	•		*	•	*						
VIVOTEK IB9380-H	•	*	•		*	*	•	-		•						0113a	
VIVOTEK IB9381-EHT	•	*	•		*	*	•	•	•	•	•					0113a	
VIVOTEK IB9381-HT	•	*	•	•	*	*	•	•	•	•	•					0113a	
VIVOTEK IB9383-HTV	•		•	•			•	•		•	•			•		1.2303.43.01h	
VIVOTEK IB9383-HV	•	*	•	•	*	*	•	•	*	•	*			•			
VIVOTEK IB9387-EH	•	*	•	•	*	*		•	•		•					0113d	
VIVOTEK IB9387-EHT	•	*	•	•	*	*	•	•	•	•	•					0113d	
VIVOTEK IB9387-EHT-A	•	*	•		*	*	•	•	•	•						0100m	
VIVOTEK IB9387-EHTV-V3	•	*	•		*	*		•	•					•		1.2201.37.01g	
VIVOTEK IB9387-H	•	*	•		*	*	•	•	•	•	•					0113d	
VIVOTEK IB9387-HT	•	*			*	*		•	•	•	•					0113d	
VIVOTEK IB9387-HT-A	•	*			*	*	•									0100m	
VIVOTEK IB9387-LPR	•	*			*	*		•		•						0113d	
VIVOTEK IB9388-HT	•	*	•	•	*	*	•	•	*	*	*					2.2002.13.01h	
VIVOTEK IB9389-EH	•	*	Ť	•	*	*	<b>•</b>	•	•	•	*					0113d	
VIVOTEK IB9389-EH-v2	•	*	•	•	*	*	•	•	*	*	*	*				1.2204.33.01d	
VIVOTEK IB9389-EHM	•	*	Ť	-	*	*		i i	•	•	*					0113d	
VIVOTEK IB9389-EHT	- i	*	Ť	•	*	*		•		•	*					0113d	
VIVOTEK IB9389-H		*			*	*					*					0113d	
		*		-	*	*	-			-	*					0113d	
VIVOTEK IB9389-HM	•	*	•	•	*	*	•	•	•	•	*						
VIVOTEK IB9389-HT	•	-	•	•			•	•	•	•	-					0113d	
VIVOTEK IB9391-EHT	•	*	•	•	*	*	•	•	•	•	•					0113d	
VIVOTEK IB9391-EHTV-v2	•	*		•	*	*	•	•	•	•	•			•		1.2201.37.01g	
VIVOTEK IP7130	•		*	*	*	*		•									
VIVOTEK IP7132	•		*	*	*	*		•		•							
VIVOTEK IP7133	•		*	*	*	*	•	•	•	•						0103b	
VIVOTEK IP7135			*	*	*	*		•	*		*						
VIVOTEK IP7142	•		*	*	*	*		•	•	•							
VIVOTEK IP7160	•	*	•	*	*	•	•	•	*	•	•						
VIVOTEK IP7161	•	*	•	*	*	•	•	•	*	•							
VIVOTEK IP7161-SS	•	*	•	*	*	•		•	*		*						
VIVOTEK IP7361	•	*	•	*	*	•	•	•	*	•	•						
VIVOTEK IP8130	•		•	*	*	*	•	•	•	•	•						
VIVOTEK IP8130W	•	- Č	Ĭ	*	*	*	•	•	•	•	Ŏ						
VIVOTEK IP8131	•	- Č	Ť	*	*	*	- i	•	- Č	•	•						
VIVOTEK IP8131W	- i	Ĭ	Ť	*	*	*		•		- i	•						
VIVOTEK IP8132	•			*	*	*	•			•	*						<u> </u>
				*	*	*					*						<u> </u>
VIVOTEK IP8133 VIVOTEK IP8133W				*	*	*					*						<u> </u>
	•		•	*	*	*	•	•		•	_						
VIVOTEK IP8151	•	•	•	_	*		•	•	•	•	•						l
VIVOTEK IP8151HP	•	*	•	*		•	•	•	•	•	*						
VIVOTEK IP8151P	•	*	•	*	*	*	•	•	•	•	•					0201c	
VIVOTEK IP8151-SS	•	•	•	*	*	*	•	•		•	*						
VIVOTEK IP8152	•	•		*	*	*	•	•		•	•						
VIVOTEK IP8152-F4	•	•	•	*	*	*	•	•	•	•	•						L
VIVOTEK IP8155HP	•	•	•	*	*	*	•	•	•	•	•						
VIVOTEK IP8160	•		•	*	*	*		•		•	*					0113a	
VIVOTEK IP8160-W		*		*	*	*					*					0113a	
VIVOTEK IP8161	•	*	•	*	*	*	•	•		•	•					0100c_20	
VIVOTEK IP8161-SS	•	*	•	*	*	*	•	•	•	•	*					0200c	
VIVOTEK IP8162	•	*	Ĭ	*	*	*	•	i i		- i	•					0200c	
VIVOTEK IP8162P	•	*	<b>†</b>	*	*	*		•	•	•	•					0200c	
VIVOTEK IP 8102P	•	*		*	*	*		•		•	-	<u> </u>				02000	<u> </u>
VIVOTEK IP8165HP		*		*	*	*					•					0200c	<u> </u>
			-	*	*	*		-	-		-						<u> </u>
VIVOTEK IP8166	•			*	*			•	•	•						0113a	
VIVOTEK IP816A-HP			•	*	*			•		•	•						

Camera Model	Com	pression	ronnat	20	oom Cor	101	Do	asic Funct	1	-		Auva	inced Functio		Remark	<b>—</b>
	MJPEG	MPEG -4	H.264 H.26	5 Pan/ Tilt	Optical Zoom	Digital Zoom	Motion Detection	Digital Input	Audio (Besides HTTP)	Two- way Audio	Edge Record (RTSP)	Supported IVA	Al Search (Metadata)	Advanced Right-Click Menu	Camera Firmware/ Note	N ot
VIVOTEK IP816A-LPC Kit	•		• *	*	•	•	•	•	•	Audio *	(KISP)					
VIVOTEK IP816A-LPC(18mm)	•		• *	*	*	•			*	*						<u> </u>
VIVOTEK IP816A-LPC(40mm)			• *		*	•		•	*	*						-
VIVOTEK IP810A-LPC(401111) VIVOTEK IP8172			• *		*	•		•	•	•						<u> </u>
VIVOTEK IP8172 VIVOTEK IP8172P			-	_	*					•						
	•		-	*	*			<b>—</b>		-						
VIVOTEK IP8173H	•	*	<u> </u>			•	•	*	•	*						
VIVOTEK IP8330	•		-	_	•	•	•		*	*						
VIVOTEK IP8331	•	•	-		•	•	•	•								
VIVOTEK IP8332	•	•	• *		*	•	•	•	•	*						
VIVOTEK IP8332-C	•	*	• *	*	*	•	•	•	*	*					0201a	
VIVOTEK IP8332-SS	•	*	• *	_	*	•	•	•	•	*						
VIVOTEK IP8335H	•	*	• *		*	•	•	•	•	•						-
VIVOTEK IP8336W	•		• *				•	•	•	*						
VIVOTEK IP8337H-C	•		• *	_	•	•	•	•	•	*						<u> </u>
VIVOTEK IP8352	•		• *		*	•	•	•	•	•						
VIVOTEK IP8354-C	•	*	• *		*	•	•	•	*	*						
VIVOTEK IP8355EHN	•	*	• *	*	•	•	•	•	•	*					0201c	
VIVOTEK IP8355H		*	• *	*			•		•	•						
VIVOTEK IP8361			• *	*		•	•		•	•						
VIVOTEK IP8361-C			• *	*			•			*						
VIVOTEK IP8362			• *	•		•	•									
VIVOTEK IP8364-C		*	• *	*	*	•	•	•	•	*					0101b	
VIVOTEK IP8365EH		*	• *	*	*	•	•		•						0100m	
VIVOTEK IP8365H		*	• *	*	*	•	•		•						0102e (1.2a.a2.1.38)	
VIVOTEK IP8371			* *	*	*	•	•	•	•							
VIVOTEK IP8371E	•	•	* *	*	*	•	•	•	•	•						
VIVOTEK IP8372	•	•	* *	*	*	•	•	*	•	Ó						
VIVOTEK IP9165-HP	•	*	• •	*	*	<b>•</b>	<b>•</b>	•	•	<b>•</b>					0113d	
VIVOTEK IP9165-HT	•	*	• •	_	*	•	•	•	•	•					0113d	
VIVOTEK IP9165-HT-v2	•	*	• •	-	*		- i	•	- i	•	•		•		2.2003.34.01n	1
VIVOTEK IP9165-LPC	•	*	$\mathbf{\dot{\bullet}}$		*	<b>i</b>		•		•	•				0113d	1
VIVOTEK IP9165-LPC-v2	•	*	• •	_	*				•	ě			•		1.2201.37.01g	1
VIVOTEK IP9167-HP	•	*	• •	*	*	•				•					0113a	-
VIVOTEK IP9167-HT		*	$\mathbf{\dot{\bullet}}$	*	*	•				•					0113a	
VIVOTEK IP9171-HP		*		_	*	•	•		•	•					0113a	
VIVOTEK IP9181-H		*	•••		*										0113a	-
VIVOTEK IP9181-HT-v2		*	• •	_	*	•									1.2201.37.01g	+
VIVOTEK IP9181-IPC-v2		*			*	-	-						•		1.2201.37.01g 1.2201.37.01g	
	•	*		*	*	•	•	•	•	•			•			
VIVOTEK IP9191-HP	•	*	• •	_	*	•	•	•	•	•					0113d	
VIVOTEK IP9191-HT	•		• •			•	•	<b>—</b>	•	•					0113d	+
VIVOTEK IP9191-HT-v2	•	*	• •	_	*	•	•	•	•	•			•		1.2201.37.01g	
VIVOTEK IP9191-LPC-v2	•	*	• •	*	*	•	•	•	•	•			•		1.2201.37.01g	<u> </u>
VIVOTEK IT9360-H	•	*	• •	_	*	•	•	*	•	*					0113a	
VIVOTEK IT9368-HTV	•	*	• •	_	*	•	•	*	•	*					0113a	+
VIVOTEK IT9380-H	•	*	• •		*	•	•	*	•	*					0113a	
VIVOTEK IT9388-HT	•	*	• •	-	*	•	•	*	•	*					0113a	<u> </u>
VIVOTEK IT9389-H	•	*	• •		*	•	•	•	•	•					0113d	<u> </u>
VIVOTEK IT9389-HT	•	*	• •	-	*	•	•	*	•	*					0113d	<u> </u>
VIVOTEK IZ9361-EH	•		• •	*	*	•	•	•	•	•					0113a	
VIVOTEK MA8391-ETV	•	*	• *	*	*	•	•	•	•	•					0106a	
VIVOTEK MA9321-EHTV		*	• •	*	*	•	•		•	•					0113a	
VIVOTEK MA9322-EHTV		*	• •	*	*										0113a	
VIVOTEK MA9322-EHTV		*	• •	*	*										0114c	
VIVOTEK MD7560	•	*	• *	*	*	•	•	•	•	*					0100j	
VIVOTEK MD7560D	•	*	• *	*	*	•	•	•	•	*					0102a	
VIVOTEK MD7560X	•	*	• *	*	*	•	ě	•	•	*					0100e	
VIVOTEK MD8531H	•		• *	•	•	ě	- Č	•		*						
VIVOTEK MD8562	•		• *		•	<b>i</b>	- i	*	- i	*						
VIVOTEK MD8562D	•		• *		*	•	•	•	•	*		1	1			<u> </u>
VIVOTEK MD8563-DEHF2		*	• *		*	•	•		•	*	L		-		0113a	<u> </u>
		*	• *		*	•				*					0113a	+

Camera Model	Cón	pressio	on Format	20	oom Cor	itrol	Ba	asic Funct	1	1		Adva	nced Functio	n	Remark	
		MPEG		Pan/	Optical	Digital	Motion	Digital	Audio	Two-	Edge	Supported	Al Search			Not sup
	MJPEG	-4	H.264 H.265	Tilt	Zoom	Zoom	Detection	Input	(Besides	way	Record	IVA	(Metadata)	Advanced Right-Click Menu	Camera Firmware/ Note	other p
					200111			-	HTTP)	Audio	(RTSP)		(metadata)			CMS,
VIVOTEK MD8563-EH	•	*	• *	*	*	•	•	•	•	*					0113a	
VIVOTEK MD8563-EHF2		•	• *	*	*	•	•	•	•	•					0113a	
VIVOTEK MD8563-EHF4			• *	*	*				•						0113a	
VIVOTEK MD8564-EH	•	*	• *	*	*		•		•	*					0113a	
VIVOTEK MD8565-N	•	*	• *	*	*	•	•	•	•	*					0113a	
VIVOTEK MD9560-DH	•	*	• •	*	*	•	•	*	•	*					0113a	
VIVOTEK MD9560-H	- ·	*	$\bullet$ $\bullet$	*	*	•	•	*	- i	*					0113a	
VIVOTEK MS8391-EV		*	• •	*	*	Ť	•	•		•					0106a	
VIVOTEK MS8392-EV				*	*			-	•						01000	
	•	•		*		•	•	•	•	•						
VIVOTEK MS8931-EV	•	*			*	•	•	•	•	*					0101e	
VIVOTEK MS9390-HV	•	*	$\bullet$ $\bullet$	*	*	•	•	*	•	*					0113d	
VIVOTEK PD8136	•		• *			•	•		•	*						
VIVOTEK PD8136W			• *						•	*						
VIVOTEK PT8133	•		• *			•	•		•	•						
VIVOTEK PT8133W	•		• *	•		•	•	*		•						
VIVOTEK PZ71X1	•	*	• *	•	•	•	•	•	•	*					0100h	
VIVOTEK PZ71X2	•	•	• *	Ť		•	•		•	*						
	_			-	-	-										
VIVOTEK PZ8111	•	•		•	•	•	•	•	•	•						
VIVOTEK PZ8111W	•	•	• *	•	•	•	•	•	•	•						
VIVOTEK PZ8121	•	•	• *		•	•	•	•	•	•					0200c	L
VIVOTEK PZ8121W	•	•	• *		•	•	•	•	•	•						
VIVOTEK SD8111	•		• *				•		•	•						
VIVOTEK SD8121	•	•	• *	•	•	•	•	•	•	•						
VIVOTEK SD8121-SS	•	•	• *	Ō	<b>O</b>	ě	•	•	•	*						
VIVOTEK SD8161	•		• *	Ŏ	Ĭ	•			- Č	•						
VIVOTEK SD8311E				•	-	•	•	-		Ť						
	•	-		-	•	-	-	-	-							
VIVOTEK SD8312E	•	•		•	•	•	•	•	•	•						
VIVOTEK SD8313E	•	*	• *	*	*	•		•	•	•					0200e	
VIVOTEK SD8314E			• *		•		•	•	•	•						
VIVOTEK SD8316E	•		• *			•	•	•	•	•						
VIVOTEK SD8321E	•	•	• *		•		•		•	•						
VIVOTEK SD8322E	•	*	• *	•		•	•	•	•	•					0100f	
VIVOTEK SD8323E	•	*	• *	•	•	•	•	•	•	•					0101a	
VIVOTEK SD8323E-SS	- i	*	• *	Ó	ě	<b>•</b>	•	•	- i	*					0101a	
VIVOTEK SD8324E		*	• *	*	*	•			•	•					0102e (1.2a.a2.1.38)	
		*								-						
VIVOTEK SD8326E	•			•	•	•	•	•	•	•					0101a	
VIVOTEK SD8333-E	•	*	• *		•	•	•	•	•	•					0101a	
VIVOTEK SD8362E	•	*	• *				•		•							
VIVOTEK SD8362E-SS			• *				•		•	*						
VIVOTEK SD8363E			• *		•		•	•	•							
VIVOTEK SD9161-H DCS	•	*	• •	•	•	•	•	•	•	•					0113a	
VIVOTEK SD9161-H-V2	- Č	*	$\bullet$ $\bullet$	Ŏ	•	•	•	•	•	ě	•		•		1.2203.35.01e	
VIVOTEK SD9361-EHL	•	*	$\bullet$	Ō		•			- Č	i i					0113a	
VIVOTEK SD9362-EH		*		-	•	-	•			Ť					0113a	<u> </u>
	_	*				-	-			-					0113a	
VIVOTEK SD9362-EHL	•		• •	+ <b>-</b>	•	•	•	•	•	•						
VIVOTEK SD9362-EH-v2	•	*	••	•	•	•	•	•	•	•					0113a	
VIVOTEK SD9363-EHL @®	•	*	• •	•	•	•	•	•	•	•					0113a	I
VIVOTEK SD9363-EHL-v2 @s	•	*	• •			•	•		•	•					0113a	
VIVOTEK SD9364-EH	•	*	• •		•	•	•	•	•	•					0113a	
VIVOTEK SD9364-EHL		*	• •		•		•		•						0113a	
VIVOTEK SD9364-EHL-v2		*	• •			•	•	•	•	•					0113a	
VIVOTEK SD9364-EH-v2	- Č	*	$\bullet$	Ŏ	•	ě	•	•	•	Ŏ					0113a	
VIVOTEK SD9365-EHL	•	*	$\bullet$	Ŏ	<b>•</b>	•		•	- Č	<b>•</b>	·				0113a	
VIVOTEK SD9366-EH		*	$\bullet$	•	•	•	•		•		<u> </u>				0113a	<u> </u>
		-		-	-	-	-	-		-				1		<u> </u>
VIVOTEK SD9366-EHL	•	*	• •	•	•	•	•	•	•	•					0113a	l
VIVOTEK SD9366-EH-v2	•	*	• •	•	•	•	•	•	•	•					0113a	
VIVOTEK SD9368-EHL	•	*	• •		•	•	•	•	•	•			•		1.2201.35.01e	
VIVOTEK SD9384-EHL	•	*	• •	•	•		•	•	•	•			•		1.2101.35.01i	L
VIVOTEK SD9394-EHL	•	*	• •	-	•	•	•	•	•	•			•		1.2201.37.01g	
VIVOTEK SF8172	•	*	• *	*	*		•		•	•						
VIVOTEK SF8172V		*	• *	*	*		•			•					0103b	
VIVOTEK SF8174	•	*	• *	*	*	ě	•	•	•	Ŏ					0103b	1

Camera Model	C	om	pressio	n Forr	nat	Zo	om Cor	ntrol	Ba	sic Functi	on			Adva	nced Functio	on	Remark	
	MJF	EG	MPEG -4	H.264	H.265	Pan/ Tilt	Optical Zoom	Digital Zoom	Motion Detection	Digital Input	Audio (Besides HTTP)	Two- way Audio	Edge Record (RTSP)	Supported IVA	Al Search (Metadata)	Advanced Right-Click Menu	Camera Firmware/ Note	Not supp other plat CMS, VE
VIVOTEK SF8174V DCS			•		*	*	*			•							0100c	
VIVOTEK VC8101	•		*	•	*	*	*	•	•	•	•	•					0113a	
VIVOTEK VC9101	•	•	*	•	•	*	*	•	•	•	•	•					2.2201.34.01d Compatible lens suggested by vendor: 1) CU9171-H (4M) 2) CU9183-H (5M, fisheye) @@@ 3) CU9171-HF (4M) 4) CU9183-HF (5M, fisheye) @@@	
VIVOTEK Video server																	14) COSTOS III (SIM, ISINC/C) 000	
VIVOTEK VC8201			*		*				•		•							
VIVOTEK VS8100			*	•	*	•	•	•	•	*	•	*					0102b	
VIVOTEK VS8102			•	•	*	•	۲	•	•		•	•						
VIVOTEK VS8801			•	•	*	•			•		•	•						
VIVOTEK People Counting Camera														•		•		
VIVOTEK SC8131			*		*	*	*		*		*	*		9			0104e	
VIVOTEK SC9133-RTL			*			*	*		*	●X2				9			1.2102.36.01p_52454_1	
VIVOTEK Joystick																		
VIVOTEK IPD-USB	*		*	*	*			*	*	*	*	*						
(DIGIEVER NVR supports VIVOTEK cameras with Generic F	RTSP method)																	
URL			Ge	neric MJ	PEG				Generic RTS	Р								
VIVOTEK VS8401										live.sdp								

Note:

1. More models are under integration and will be released soon.

2. Two-way audio: ACTi, AXIS, Brickcom, Canon, Hi-Sharp, Honeywell, Hunt, Levelone, Milesight, Only, ONVIF, Risk Captur, SONY, Sunell, TOA (5-generation camera), VIVOTEK (LAN), WatchNet

3. Edge recording: ACTi, AXIS (H.264 only), Airflying, Brickcom, Chiper, Dahua, Dynacolor, Hanwha, Honeywell, HUNT, LILIN, Milesight, Only, Pinetron, SONY(H.264 only), Tecom VIVOTEK, WatchNet

4. VB Search supports Canon cameras listed in the compatible list except VB-C series.

5. Local liveview supports ImmerVersion engine codec of H.264 and MJPEG only.

6. For camera added via ONVIF protocol, please follow below steps to set up camera event (like motion detection, digital input, tampering detection) on DIGIEVER:

(1) On DIGIEVER NVR: Enable camera event on event and action management page.

(2) On camera webpage: Enable camera event on camera setting page

7. NVR supports H.264 and H.265 through ONVIF. For MJPEG format, please use Generic\_MJPEG to add the camera.

8. NVR supports Honeywell IVA through ONVIF (by Model): Motion Detection, Advanced Motion Detection, Tampering Detection, Intrusion Detection, Loitering Detection, People Counting Threshold Notice

9. Cameras are not supported in Camera Digital Output in the Event & Action Management : Canon and TOA

10. "Setting from Camera" supported brand: AXIS(5.00 or below version), Brickcom, Canon, Chiper, Dynacolor, Hunt, iCantek, IDIS, i-Pro (, LILIN, Linksys, MEDIAEDGE, Messoa, Milesight, ONLY, ONVIF, Panasonic (except for BB-HCM, BL, BB-HCE series), PROBE, Provision ISR, Samsung, SECUBEST, Sony, TOA, Topview, VIVOTEK Note: Settings from camera doesn't support MJPEG for Panasonic cameras. NVR will switch the format to H.265, H.264 or MPEG-4 if users choose MJPEG.

Copyright ® DIGIEVER Corporation All Rights Reserved